
User's Manual



High Definition Digital Satellite Receiver

Content

Safety Precaution	3
Environment protection.....	4
1. General information	5
1.1 General Features	5
1.2 Accessories	6
2. Product Overview	7
2.1 Front Panel	7
2.2 Rear Panel	8
2.3 Remote Control Unit (RCU)	9
3. Connection with other Devices	11
3.1 Connecting to TV	11
3.2 Connecting to Antenna	12
4. Installation	14
4.1 Powering On	14
4.2 Antenna Settings	14
4.3 Factory Default	20
4.4 USALS Setup	21
5. Edit Channel	22
5.1 Edit Channel	22
5.2 Edit Favorite	24
5.3 User Channel List	25
6. Settings	25
6.1 System Settings	25
6.2 OSD Setup	27
6.3 Parental control	27
6.4 CA menu	28
7. Times	29
7.1 Time Settings	29
7.2 Event Timer	29

7.3 Sleep Timer	31
7.4 Standby hour	31
8. Expansion	32
8.1 Games	32
8.2 USB	32
8.2.1 Basic Operations	32
9. About STB	38
10. Basic Operation	39
10.1 Audio	39
10.2 Zoom In	39
10.3 Satellite List	39
10.4 EPG	40
10.5 Subtitle	41
10.6 Teletext	41
10.7 Find channel	41
10.8 Program Information	42
11. Channel List	44
11.1 OK List	44
11.2 Favorite List	45
12. USB Control	46
12.1 Recording and Timeshift	46
12.2 PVR List	47
13. Network	48
13.1 Connecting to Network	48
13.2 Connecting to Wifi (Wireless LAN) - OPTIONAL	48
13.3 Network Application	49
14. Additional Information	50
14.1 Trouble Shooting	50
14.2 Declaration of conformity	52
14.3 Technical Specification	53

Safety Precautions

This STB has been designed and manufactured to satisfy the international safety standards. Please read the following safety precautions carefully before operating this receiver.

Main Supply:

Before operating, please check the units operating voltage is 90~250V AC 50/60Hz.

Overload:

Do not overload a wall outlet, extension cord or adapter, neither use damaged power cord or touch it with wet hand as this may result in electric shock.

Liquid:

The receiver shall not be exposed to dripping or splashing water, and that no objects filled with liquids, such as base, shall be placed on the apparatus.

Ventilation:

Keep the slots on top of the receiver uncover to allow sufficient airflow to the unit. Do not put the receiver on soft furnishings or carpets. Do not expose the receiver to direct light or do not place it near a heater or in humid conditions. Do not stack other electronic equipments on top of the receiver.

Cleaning:

Plug out the receiver from the wall outlet before cleaning. Clean the receiver by a soft cloth or mild solution of washing-up liquid (no solvents).

Connection:

Disconnect the receiver from the mains when you connect it to satellite LNB or disconnect it from LNB. Failure would possibly cause damage to the LNB.

Location:

Put the receiver indoor in order to avoid lightening, raining or sunlight.

Uncover:

Do not remove the cover, to reduce the risk of electric shock. Contact qualified and licensed service personnel to repair the receiver, or contact your dealer.

Environment protection



Attention!

Your product is marked with this symbol. It means that used electrical and electronic products should not be mixed with general household waste. There is a separate collection system for these products.

Information on Disposal for Users (private households) in the European Union

Used electrical and electronic equipment must be treated separately and in accordance with legislation that requires proper treatment, recovery and recycling of used electrical and electronic equipment.

Following the implementation by member states, private households within the EU states may return their used electrical and electronic equipment to designated collection facilities free of charge*. In some countries* your local retailer may also take back your old product free of charge if you purchase a similar new one. *) Please contact your local authority for further details.

If your used electrical or electronic equipment has batteries or accumulators, please dispose of these separately beforehand according to local requirements.

By disposing of this product correctly you will help ensure that the waste undergoes the necessary treatment, recovery and recycling and thus prevent potential negative effects on the environment and human health which could otherwise arise due to inappropriate waste handling.

Information on Disposal for Business Users

In the European Union

If the product is used for business purposes and you want to discard it:

Please contact your dealer who will inform you about the take-back of the product. You might be charged for the costs arising from take-back and recycling. Small products (and small amounts) might be taken back by your local collection facilities.

In other Countries outside the EU

If you wish to discard of this product, please contact your local authorities and ask for the correct method of disposal.

1. General information

1.1 General Features

DVB-S/DVB-S2 Satellite Compliant (MPEG-II/ MPEG-IV/ H.264)

SCPC & MCPC receivable from Ku and C band satellites

Universal, Single, Single S & C Band Wideband LNB

Sensitive Tuner with Loop-Through

DiSEqC1.0/1.1/1.2/1.3 (USALS)

Unicable Supported

Blind search supported

Auto DiSEqC Search

PAL/NTSC Conversion

True full Color (32 bits) on screen display (OSD)

Storing memory: 100 satellite, 4000 transponders and 6100 channels

8 favorite group and parental lock supported

Multi-language menu supported

Multi-language audio supported

Multi-language DVB Subtitle output

7 days Electronic Program Guide (EPG)

Teletext output through VBI and OSD

USB 2.0 Interface

1.2 Accessories

- Users manual
- Remote Control Unit
- Batteries



Figure 1.Accessories

2. Product Overview

2.1 Front Panel




Figure 2. Front Panel

1. Signal LED (green)

Signal indicator.

2. Power LED (red)

Power indicator

3. Display

It displays channel information. In standby mode it displays current time.

Press front panel on the middle, above LED display, to open front panel flap:




Figure 3. Internal Front Panel

1. USB Port

USB 2.0 port

2. Power button

Switch between operation and standby modes.

3. MENU Button

Activate the main menu in viewing mode.

4. Exit Button

Exit current menu one menu level per one pressing.

5. OK Button

Enters to the highlighted sub menu in menu mode or activates the channel list in viewing mode.

[6,7]. VOL-/VOL+

Decrease / increase the volume in viewing mode and change settings in menu mode.

[8,9]. CH-/CH+

Change channel in viewing mode and move the cursor up/down in menu mode.

Card reader: Insert Conax Smart Card with golden pins down

2.2 Rear Panel




Figure 3. Rear Panel

1. LNB IN

Connect the satellite antenna cable.

2. LOOP OUT

Connect another receiver.

[3,4,5] Y PB PR OUT

Component Video output.

6. 0/12V OUT

0/12V power output.

7. RS232

Connect to PC using serial interface. Port dedicated for service.

8. ON/OFF

Power switch on/off.

9. SPDIF

Digital Audio output (Optical).

[10,11,12] VIDEO/AUDIO OUT

Connect to the TV using a RCA cable.

13. HDMI

Connect to the TV using HDMI cable.

14. Ethernet port

Connect to the internet using Ethernet cable.

15. USB2.0

USB 2.0 Host Port.

16. TV SCART

Connect to the TV using a Scart cable

2.3 Remote Control Unit (RCU)

You can control this receiver by this remote controller with full function.

1. TV/R: Switch between TV and RADIO.

2. POWER: 

Switch between operation and standby modes.

3. MUTE:  Mute audio.

4. DISPLAY: Set the HDMI mode.

5. MODE: Set the display format.

6. TIME: Setup event timer.

7. SLEEP: Set the sleep time.

8. NUMERIC KEY (0-9): Enter a TV/radio channel



Figure 4. Remote Control

number or menu option number.

9. ZOOM: Picture zooming function.

10. SUBT: Display available subtitle language list.

11. AUDIO: Display available audio list.

12. FAV: Display favorite channel list you set before.

13. SAT: Show the scanned satellite list.

14. RECALL: Move to the previous viewed channel.

15. EPG (Electronic Program Guide): Display the program guide.

16. EXIT: Exit current menu step by step.

17. CH+/CH-: Change program.

18. VOL+/VOL- : Change volume in viewing mode.

19. OK: Confirm the selected operation or display the channel list while watching a program.

20. MENU: Enter to main menu.

21. TXT: Display the teletext.

22. FIND: Quickly find channels which you want.

23. INFO: Display program information.

24. ►: Play recorder file, resume from Pause or display recording list

25. II : Pause/time shift.

26. ■: Stop Recording, stop playback or exit from timeshift.

27. ●: Start Recording.

28. I◀◀: Previous.

29. ►►I : Next.

30. ◀◀: Fast rewind.

31. ►►: Fast forward.

32. USB: Enter to USB menu.

33. F1/F2/F3/F4/F5: Optional functions.

34. ▲/▼: Page up/down in menu.

3. Connection with other Devices

The following diagram shows the connections among receiver, TV, LNB and other equipment, please read this first if you are not sure about correct connection.

3.1 Connecting to TV




Figure 5. Connecting to TV & VCR

3.2 Connecting to Antenna

To connect to the dish with one single LNB, plug-in antenna cable directly to the LNB IN.




Figure6. Connecting to Dish with single LNB

To connect to the dish with more than one LNB, connect antennas by DiSEqC 1.0 or 1.1 switch. Connect receiver LNB IN to DiSEqC port output. When using DiSEqC 1.0 or 1.1 switch, remember to set proper DiSEqC port in Installation Menu.




Figure7. Connecting to Dish with many LNBs using DiSEqC switch

4. Installation

After connecting antenna you should install the receiver after powering on your product for the first time after purchase.

Tip: The default password is **0000**. If you have forgotten your password, please contact your local product distributor.

4.1 Powering On

1. Connect the power cord of the product to a wall outlet.
2. Ensure the **ON/OFF** switch at the rear of the product is switched to **ON**.
3. Power on by pressing the **STANDBY** button on the remote control or the **STANDBY** button at the front of the product.

4.2 Antenna Settings

Antenna Settings allows you to configure the antenna setting parameters.

Menu->INTALLATION->Antenna Settings

1. **Satellite:** Displays currently chosen satellite. Press the **VOL+/VOL-** button to change.
2. **Transponder (TP for short):** Press the **VOL+/VOL-** button to change the TP.
3. **LNB Type:** Press the **VOL+/VOL-** button to change the LNB frequency.



4. **LNB Power:** Press the **VOL+/VOL-** button to select the required LNB power.
5. **22kHz:** Press the **VOL+/VOL-** button to select **ON**, **OFF** or **Auto**.
6. **DiSeqC 1.0:** Press the **VOL+/VOL-** button to select the required DiSeqC1.0 input.
7. **DiSeqC 1.1:** Press the **VOL+/VOL-** button to select the required DiSeqC1.1 input.
8. **Motor:** Press the **VOL+/VOL-** button to select DiSeqC1.2 or USALS motor.
9. **Scan Mode:** Press the **VOL+/VOL-** button to choose available scan options: All Channels/FTA channels/HD channels/ SD channels/ TV channels/ Radio channels/ FTA TV channels/ FTA Radio channels/
10. **Start search:** Press the **VOL+/VOL-** button to select Satellite & Multi-Sat & Blind scan & Transponder & Multi-Transponder which you want to start search.

4.2.1 Antenna Settings for Satellite

Move cursor to **Satellite** position. Press **OK** button. You can see the pre-stored Satellite list. In this menu, you can execute Select, Add, Move, Delete, Rename Satellites by pressing **VOL+/VOL-** button.

➤ Select

In this menu, you can press the **CH+/CH-** keys choose the satellite which you want to use, and then press the **OK** to confirm the setting.

➤ Add

Select the **Add** using the **VOL+/VOL-** keys. Here you can input new Satellite angle, Satellite Direction (East, West), Band (Ku, C). Press **OK** to confirm the setting and this new satellite will be added to the end of the Satellite list.

➤ Move



In this menu, you can Select the satellite that you want to move from the satellite list using the **CH+/CH-** keys. Select satellite and press **OK**, you will be asked where to move the satellite, input the destination number and press **OK**. Then you can move another one satellite from one position to other.

➤ **Delete**

You can delete unused satellites. Select the satellite that you want to delete from the satellite list. You will be asked to confirm whether delete the satellite or not. If you select YES, all the channels and transponders in the selected satellite will be deleted. Press **OK** key, and the selected satellite will be deleted.

➤ **Rename**

You can also change the satellite name. Select the **Rename** using the **VOL+/VOL-** keys. Press **OK** key and select the character which you want to edit the name. Confirm by pressing **BLUE** button.



4.2.2 Antenna Settings for Transponder

If you change the satellite, the transponders list will be changed automatically. You will find the transponder list of selected satellite here. In this menu, Press the **VOL+/VOL-** or **OK** button you can see the pre-stored Transponder list, and you can execute Select, Add, Delete, Edit Transponders by **VOL+/VOL-** keys.

➤ **Select**

In this menu, you can press the **CH+/CH-** keys choose the



Transponder which you want to use, then press **OK** to confirm the setting.

➤ **Add**

Here you can input new Transponder frequency, choose polarization (Vertical, Horizontal), input new Symbol rate, and choose FEC: 1/2, 2/3, 3/4, 6/5, 7/8, Auto . Press **OK** to confirm the settings, and this new Transponder will be added to the TP list in ascending order sorted by frequency.

➤ **Delete**

You can delete the Transponder of the Satellite. Select the Transponder that you want to delete from the TP list. You will be asked to confirm whether delete the Transponder or not. If you select YES, all the channels in the selected Transponder will be deleted. Press **OK** key, and the selected Transponder will be deleted.

➤ **Edit**

In this menu, you can press the **CH+/CH-** keys choose the Transponder which you want to Edit, press **OK** to confirm. Here you can change the Transponder frequency, polarization (Ver, Hor), symbol rate and FEC, then press **OK** to confirm your new settings.

4.2.3 Search Channels from Satellite

A: Satellite Search

1. Highlight the **Satellite** position and press the **OK** button to enter satellite list. Select one satellite you want to search.
2. Complete the antenna settings of this satellite.
3. Highlight the **Start Search** and select **satellite** then press the **OK** button to confirm.

B: Multi Satellites Search

1. Highlight the **Start Search** and select **Multi-sat** then press the **OK** button.
2. Highlight the satellites in the satellite list, but make sure they are all configured to

your DiSEqC Switch before press the **OK** to mark them.

3. Press **Exit** will start searching programs of the satellites you have marked.

C: Blind Search

1. Highlight the **Satellite** and press the **OK** button to enter satellite list. And then select one satellite you want to search.

2. Complete the antenna settings of this satellite.

3. Highlight the **Start Search** and select **Blind Search** then press the **OK** button to confirm.

D: TP Search

1. Highlight the **Satellite** and press the **OK** button to enter satellite list. And then select one satellite you want to search.

2. Complete the antenna setting of this satellite.

3. Highlight the **Transponder** and press the **OK** button to enter **TP** list. And then select one transponder you want search.

4. Highlight the **Start Search** and select **Transponder** then press the **OK** button to confirm.

E: Multi TP Search

1. Highlight the **Satellite** and press the **OK** button to enter satellite list. And then select one satellite you want to search.

2. Complete the antenna setting of this satellite.

3. Highlight the **Start Search** and select **Multi-Transponder** then press the **OK** button to confirm.

4. Highlight the transponders in the TP list press the **OK** to mark them.

5. Press **Exit** will start searching programs of the transponders you have marked.

4.2.4 Antenna Settings for Motor

Menu-> INTALLATION ->Antenna Settings->Motor

1. Motor Mode:

Select **DiSEqC 1.2** or **USALS** using the **VOL+/VOL-** button.

DiSEqC 1.2: General motor antenna using DiSEqC 1.2.

USALS: Motor antenna using USALS system.



➤ Move Auto[W/E]

Press **VOL+/VOL-** button, the dish will be motorized to East/West continuously, it will stop until it find the best signal.

➤ Move west-east

Press **VOL+/VOL-** button, the dish will be motorized to East/West step by step, until you find the best signal showed on the signal bar.

➤ Fine Tuning(1)

Input digital button to set the moving step

➤ Store Position

Save the current position you searched.

➤ Go to Position

Press **OK** button to move the dish to the position which you saved.

➤ **Go to Reference**

Press **OK** button to move the dish to 0 position.

➤ **Set West Limit**

You can set the maximum motor limit for both **West** to prevent damage to the antenna.

➤ **Set East Limit**

You can set the maximum motor limit for both **East** to prevent damage to the antenna.

➤ **Disable Limit**

Disable West limit and East limit.

➤ **Go to X.X**

Press **OK** button to move the dish to the **USALS Setup**.

Tip: Before you use **USALS**, you should go to Main **Menu** → **SETTINGS** → **USALS Setup** to set your local position firstly.

4.3 Factory Default

In case of any difficulties or wrong settings, You can restore the product to the factory default settings.

Warning: Please note that once you perform **Factory Default** -> **All**, all data and settings will be deleted.

1. **Menu->INSTALLTION -> Factory Default**

2. Input the password. Default password is 0000. In case password was changed, input your own password.

3. Highlight the option you want and press the **OK** button to execute it.

1) **All**: All data and settings will be deleted.

Tip: If you select “yes”, all data and setting will be lost. Then waiting a moment, you will view the OSD language menu where you can select the language according your mind.

2) **Channel List Only**: All channels data will be deleted.

3) **Radio Channel Only**: All radio channels data will be deleted.

4) **Scramble Channel Only**: All scramble channels data will be deleted.

4.4 USALS Setup

Menu->Satellite->USALS Setup

If you set the Motor Mode to USALS, you need set the longitude and the latitude in USALS Setup.

Setup By Country: Press the **Red** button, you can choose the country, press **OK** button, you will view the city in this country that's you select.



5. Edit Channel

5.1 Edit Channel

Menu **Edit Channels** enables to move, delete, rename, lock/unlock, swap the channels in the channel list conveniently.

Menu->EDIT CHANNEL->TV Channels

Menu->EDIT CHANNEL-> Radio Channels

Tip: Radio Channels operation similar to the **TV Channels**.

Tip: in Edit Channel->TV channels you can press the **Sat** button to choose different satellite according to the **help** information, press **OK** to confirm, then all the channels of this sat will be displayed.



1. Move Channels

1) Highlight the **Move** function using **VOL+ / VOL-** button and Press **OK** to enter.

2) Highlight the channel you want to move and press **OK** to select the channel. You will see move sign instead of channel number.

3) Press the **CH+/CH-** button to move to new destination on the channel list and press the **OK** button, or press the **NUMERIC(0-9)** buttons to send channel to new destination in the channel list and press the **OK** button.



1.1 Move Group Channels

- 1) Highlight one channel you want to group move. Then press the **RED** button to mark the channel.
- 2) Press the **CH+/CH-** or **VOL+/ VOL-** button to highlight other channels you want to group move. Then press the **RED** button to sign the channel one by one.
- 3) Press the **CH+/CH-** or **VOL+/ VOL-** button to the new destination in the channel list and press **OK** to confirm. Marked channels will be placed in this position.

2. Delete Channels

- 1) Highlight the **Delete** function using **VOL+/ VOL-** button.
- 2) Press the **CH+/CH-** to highlight the channel you want to delete, press the **OK** button to sign the channel.
- 3) Press the **EXIT** button, select **Yes** in confirmation window to delete chosen channels.

3. Lock/unlock Channels

Note: before using Channels lock, go to **Menu->SETTINGS->Parental Control**, change position Edit Channel Lock to **YES**.

- 1) Highlight the **Lock** function using **VOL+/ VOL-** button.
- 2) Highlight the channel you want to lock, press the **OK** button to confirm.
- 3) Input the password to lock the channel. If you want to lock another channel, you will not be asked to Input the password again until you press **EXIT**.

Note: If the highlighted channel is locked, press the **OK** button is switched into Unlock.

4. Rename Channels

- 1) Highlight the **Rename** function using **VOL+/ VOL-** button.
- 2) Highlight the channel you want to rename, press the **OK** button.
- 3) Enter a channel name directly using the keyboard displayed on the screen and

press the **BLUE** button to complete.

5. Swap Channels

- 1) Highlight the **Swap** function using **VOL+ / VOL-** button.
- 2) Highlight the channel you want to swap with another.
- 3) Press the **OK** button to confirm.
- 4) Input new position of a channel and press **OK**. Channels position will be replaced.

5.2 Edit Favorite

Menu->EDIT CHANNEL-> Favorites

You can add or remove channels from the favorite groups.

1. Press the **VOL+ / VOL-** button to change the favorite group .
2. Highlight the channels you want to add or remove from that favorite channel list and press the **OK** button. to mark the channel as selected favorite group.
3. Press **RED** key to rename favorite group.
4. Press the **EXIT** button to exit the menu and save it.
5. You can access favorite list by pressing FAV button on remote.

Note: to change order of channels inside favorite lists, press FAV button, choose FAV list you want to modify order and press GREEN button to Edit order of channels.

Note: If you select a favorite list, press the **CH+ / CH-** button can only change the channels in this favorite list and press the **OK** button can only display the channels



in this favorite list. To exit from FAV list press **OK** button to display list, and press **CH+/CH-** button until you switch to All channels position.

5.3 User Channel List

User Channel List allows you to save or load all the data and settings.

1. **Menu->EDIT CHANNEL -> User Channel List->Save User Data**
2. **Menu-> EDIT CHANNEL -> User Channel List->Load User Data**

6. Settings

6.1 System Settings

Menu->SETTINGS->System Settings

1. **Menu Language:** Set the menu language.
2. **Audio1:** Set the preferred audio language.
3. **Audio2:** Set the sub-prime audio language.
4. **Subtitle language:** set the language of subtitles.



5. **Teletext language:** set the language of Teletext.

6. **Digital Audio:** If a channel has AC3 and PCM audio language at the same time, when you select **RAW** it will set AC3 audio language as default output and when you select **PCM** it will set PCM audio language as default output.

7. **SCART output:** you can choose between different SCART video signal output: CVBS and RGB

8. **Auto Channel Selection:** If you set **ON**, in the channel list will play automatically when you highlight the channel. If you set **OFF**, in the channel list when you highlight the channel, you should press the **OK** button to play it.

9. **Auto Exit CH List:** If you set **ON**, the channel list will disappear when you press OK on a Highlighted channel. If you set **OFF**, the channel list will disappear when you press OK on a playing channel.

Note: move the cursor down to see another part of menu.

10. **Recall List:** You can turn Recall List on or off. If you set ON, when you press Recall button of RCU you can get the recall list of all programs recently watched. If you set OFF, when you press recall button you can go back to the last program you have selected.



11. **Low Power Standby:** If you set ON, when standby the power consumption is low when standby. If you set OFF, when standby the power consumption is same as power on.

12. **Front panel Light:** Allows to adjust setting of 4-digit LED display on front panel. There are 5 brightness levels available.

6.2 OSD Setup

Menu->SETTINGS->OSD Setup

1. **Menu Transparency:** Set the transparency of all menus.
2. **TXT Transparency:** Set the transparency of teletext.
3. **Display Mode:** Set the HD screen resolution format between 1080p, 1080i, 720p, 576i or 576p. You can also change this setting by pressing **DISPLAY** button on remote, while watching TV.
4. **TV Type:** Set the TV Type on **PAL/NTSC/Auto** state.
5. **Screen Mode:** Set the display format according to the screen ratio. Select TV screen mode either 4:3 or 16:9 according to the TV type, or press the **MODE** button of RCU directly.
6. **OSD Timeout:** Set the time of disappearing OSD items, for example when switching channels.

6.3 Parental control

Menu->SETTINGS->Parental Control

1. **Password Lock:** General enabling/disabling of all receivers locks
2. **Installation Lock:** By choosing YES, you can set password for entering to main menu functions.
3. **Edit Channel Lock:** By choosing YES, you can enable locking channels in channel edit menu.
4. **Age Rating:** allow to set protection level. Warning! This function depends on information from signal, in case no information function will not work!

5. **Change PIN:** allow to change PIN. Input new PIN and confirm it by inputting again. Remember your new PIN.

6.4 CA menu

Receiver provides one Conditional Access slot for Smart Card. Receiver has build in module with CONAX system. By using cards in this system provided by operators, it is possible to watch many scrambled channels coded in this system. This menu shows detailed information about card inserted into card reader module. Insert Card with golden pins down.

Note:

All information showed in this menu and submenu are coming from inserted card. In case if anything is wrong, it could be card problem. After inserting the card correctly at any time, a message-box will show on the screen with message about detecting the card, in "card info" menu all available information will be displayed.

7. Times


7.1 Time Settings

Menu->TIMES->Time Settings

Time Settings will set the time mode, time zone and summer time.

1. Time Mode

You can switch the Time Mode to **Auto** or **Manual** by pressing **VOL+/VOL-** button. If the Time Mode is **Manual** you can change the current time and current date.



2. Time Offset

Set the time zone according to your country/city.

3. Summer Time

If summer time is used, correct the current time by pressing **ON** by **VOL+/VOL-** button.

7.2 Event Timer

Event Timer You can set timer events.

It will record or play the program automatically according to the timer event settings.



1. To add timer press **Menu->TIMES-> Event Timer->(RED) Add**, or in **EPG** menu press **RED** button or during watching press **TIME** button directly.
2. Press the **RED** button to setup a timer, and press the **OK** button to save the timer after setup.

Channel: Select the Channel from Channel List.

Date: Input start date of the timer.

Start/Stop: Set Start time and Stop time of the timer.

Repeat:

- <1X> only one time.
- <Day> Repeat every day.
- <1 Week> Repeat the channel once a week.
- <1-5> Repeat the channel from Monday to Friday.
- <6-7> Repeat the channel from Saturday to Sunday.

Standby when Stop

If set **YES**, the receiver will go to standby mode after the timer, if set **NO** it won't be standby.

Record:

If set **YES**, only if there is a USB device, it will be recorded automatically when the timer is started. And the recorded PVR will be saved in USB device. If set **NO**, event will not be recorded, just receiver will switch to set channel.

3. In **Event Timer** menu, highlight one event, press the **YELLOW** button will cancel this timer and press the **GREEN** button can go to edit this timer.

7.3 Sleep Timer

SLEEP Timer can set the automatic turn off receiver after selected time.

1. Menu->TIMES-> Sleep Timer.
2. Press the **VOL+/VOL-** button to select the option or input the number at "-- M" option.
3. Press the **OK** button to save.

7.4 Standby hour

Standby hour can show current time on front panel display in standby mode.

1. Menu->TIMES-> Standby hour.
2. Press the **VOL+/VOL-** button to select the option. If set ON, the current time will shown on the front panel when standby.
3. Press the **OK** button to save.

8. Expansion

8.1 Games

Menu->EXPANSION-> Games

This menu offers many funny games you can play.

8.2 USB

Menu->EXPANSION-> USB or press the **USB** button directly

With **USB** you can play many kinds of media files, you can record programs and playback it and you can do various operations when using USB HDD or USB disk.

Note: receiver supports FAT, FAT32 and NTFS format USB disk or USB HDD. For recording programs use high speed USB device. Using too slow USB devices can cause that recorded files will be useless.

8.2.1 Basic Operations

1. Tool

➤ Rename Files

- 1) Highlight the file or folder.
- 2) Press the **RED** button and Highlight the **Rename**.
- 3) Press the **OK** button can rename the file or folder.

➤ Delete Files

- 1) Highlight the file or folder.



2) Press the **RED** button and Highlight the **Delete**.

3) Press the **OK** button can delete the file or folder.

➤ **Move Files**

1) Highlight the file or folder.

2) Press the **RED** button and Highlight the **Move to**.

3) Select a destination folder.

4) Press the OK button to move the highlight folder or file to destination folder.

➤ **Copy Files**

1) Highlight the file or folder.

2) Press the **RED** button and Highlight the **Copy to**.

3) Select another disk partition.

4) Press the OK button to copy the highlight folder or file to disk partition which you selected.

➤ **Create New Folder**

1) Press the **RED** button and Highlight the **Create New Folder**.

2) Press the **OK** button to create a new folder in current folder

➤ **Sort**

1) Press the **RED** button and Highlight the **Sort**.

2) Select the sort type. (First Name/Date/Size)

3) Press the **OK** button to sort by sort type which you selected.

➤ **Format Disk**

1) Highlight a disk partition or enter a disk partition.

2) Press the **RED** button and Highlight the **Format Disk**.

3) Press the **OK** button and then select a format mode (Fat and NTFS). Then press **OK** button to confirm format. Warning! After formatting, all the files in current disk partition will be irreversibly lost.

2. Upload

➤ **Upload Data to USB (channels database)**

1) Enter the USB disk.

2) Press the **YELLOW** button and highlight the **Upload Data to USB**.

3) Press the **OK** button can upload the data and setting to USB disk.

➤ **Upload to FTP (Optional)**

1) Highlight the file or folder.

2) Press the **YELLOW** button and highlight the **Upload to FTP**.

3) Press the **OK** button can upload the highlight file or folder to FTP.

Note: this function depend on FTP server. Make sure you configure properly server connection and your FTP server support it.

8.2.2 Setting

1. Play Mode

➤ **Loop**

Set the Loop state on **Normal**, **Reverse**, **Random**, **Single** or **Off**.

➤ **Slide Show Interval**

Set the Slide Show Interval from **2S-10S**.



➤ **Photo View Mode**

Set the Photo View Mode state on **Full Screen**, **2x2 Thumbnail** or **2x3 Thumbnail**.

2. PVR Setting

➤ **Record Partition**

Select the Partition where save your record or other result of your operation.

➤ **Record Mode**

Set the Record Mode **Channel** or **Transponder**. For standard recording set it to **Channel**.



➤ **Record Type**

Set the Record Type **TS** or **PS**.

➤ **Record Time**

Set the Record Default Time **Off, 30, 60, 90, 120** minute or input number directly.

➤ **Auto Timeshift**

Set to start the Timeshift automatically, after every switching channel.

➤ **Timeshift Buffer Size(MB)**

Set the Timeshift Buffer Size **off, Auto, 100, 200, 400, 800, 1600, 3200, 6400**MB.

➤ **Timeshift Need Save**

Set the Timeshift if need to Save .

➤ **Play Start Pos**

When playing the recorded file, set the Play Start Pos to start playback from beginning of the file or from last watched position (if before stopped to play by manual exiting).

➤ **FTP Upload (optional)**

Set the stream of recording whether upload to FTP or not.

8.2.3 Play Files

1. Music

- 1) Press the **VOL+/VOL-** to highlight the **Music**.
- 2) Press the **CH+/CH-** to change the folder or file and press the **OK** button to open the folder or play the music file. It supports ***.ogg**, ***.wav** and ***.flac** format music files.



OK: Play the selected file.

CH+/CH-: Change the highlighted item.

▶: Play the file.

■ : Stop playing file.

I◀◀: Play the previous file.

▶▶I: Play the next file.

◀◀: Fast rewind.

▶▶: Fast forward.

PAUSE/||: Pause.

VOL+/VOL- : Adjust volume.

EXIT: Exit playing state and return to file list menu.

2. Photo

1) Press the **VOL+/VOL-** to highlight the **Photo**.

2) Press the **CH+/CH-** to change the folder or file and press the **OK** button to open the folder or play the picture. It supports ***.bmp**, ***.jpg**, and ***.gif** format photos.



Tip: You can press the **Green** button to go to **Play Mode** Set the **Photo View Mode** state on **Full Screen**, **2x2 Thumbnail** or **2x3 Thumbnail** in the **USB** menu. The picture followed is 2x2 Thumbnail mode.

OK: View the photo.

CH+/CH-/VOL+/VOL-: Highlighted the previous/next photo when photo view mode is **2x2 Thumbnail** or **2x3 Thumbnail**. **VOL+/VOL-** button also can rotate the picture when photo display of full screen.

I◀◀: Play the previous file.

▶▶I: Play the next file.

PAUSE/||: Pause.

ZOOM: Zoom in pictures, the zooms change as follows: x1 ->x2->x4 ->x8 ->x16 ->x1.

EXIT: Exit the current menu.

3. PVR

- 1) Press the **VOL+/VOL-** to highlight the **PVR**.
- 2) Press the **CH+/CH-** to change the folder or file and press the **OK** button to open the folder or play the PVR file.

Note: Recorded files are saved as default in folder named **ALIDVRS2**.

OK: View play list or play the highlighted file in the play list.

►: Display playing progress.

PAUSE/||: Pause or Step.

■: Stop playing file.

◀◀: Fast rewind.

▶▶: Fast forward.

◀◀ or **CH+:** Play the previous item, from the recorded programs list.

▶▶ or **CH-:** Play the next item, from the recorded programs list.

INFO: Display playing progress. In this menu, press the **INFO** button again to display the EPG information.

AUDIO: Set the audio language. (OPTIONAL)

SUB: If the file has subtitle, press the **SUB** button can change the subtitle.

TXT: If the file has teletext, press the **TXT** button can display the teletext.

Find or (0-9): Jump to the valid time that you input.

VOL+/VOL-: Jump to forward or rewind of a time interval when info bar display.

Page Up: Mark on current time when info bar display.

Page Down: Jump to mark when info bar display.

EXIT: Exit the current menu.

4. Play List

You can play the movie/photo/music/PVR files in the Play List.

- 1) In the **USB Menu** highlight a **photo/music/PVR** file and press the **FAV** button to mark it, then press the **GREEN** button to enter the **Play List** menu, you will see the files marked included in play



list.

- 2) In the **photo/music Play List**, press **FAV** key to add the all available files to the Play List. (Just according to the help information)
- 3) In the **movie/ photo/music Play List**, highlight the movie/photo/music file and press the **Red** button to mark it, then move it to the destination press OK to confirm, then you can move the marked file to destination.
- 4) Press the **GREEN** button set the **Play Mode**.
- 5) Press **Yellow** key to delete highlighted file from **Play List**.
- 6) Press the **BLUE** button to delete all files from **Play list**.

9. About STB

Menu->ABOUT STB

In this menu you can find useful information about the STB, such as product name, software version, hardware version. When you need service from the dealer you need to submit this information in order to get the correct and fast after sales service.

10. Basic Operation

10.1 Audio

You can select the language you prefer in **Audio** if the current program is available in multiple audio languages.

1. Press the **AUDIO** button.
2. Press the **OK** button to select the audio language you prefer.
3. Select audio direction (**Left**, **Right**, **Stereo**) using the **VOL+/VOL-** button.
4. Press the **EXIT** button to close.



10.2 Zoom In

You can zoom in the current video picture.

1. Press the **ZOOM** button.
2. Press the **CH+/CH-/VOL+/VOL-** button to move the icon to the position you want to zoom in.
3. Press the **OK** button to display.
4. Press the **EXIT** button to close.

10.3 Satellite List

You can select or hide the satellite that you want.

1. Press the **SAT** button.
2. Highlight the satellite that you want.
3. Press the **OK** button, then it can enter the channel list which only includes the channels of this satellite.
4. Press the **RED** button to hide or show the satellite. If it is hidden, the channels of this satellite will be hidden in the channel list.
5. Press the **Green** button to delete the satellite. And all the channels in this satellite will be deleted.

10.4 EPG


You can view the EPG information of all channels in time and date order.

1. Press the **EPG** button.
2. Press the **GREEN** button to switch EPG mode between **Weekly EPG** and **Day EPG**.

Weekly EPG:

- 1) Press the **CH+/CH-** button to change EPG event.
- 2) Press the **VOL+/VOL-** button to change the date, and it displays the EPG list in one day of the selected channel.
- 3) Highlight the EPG event which you want, press the **RED** button to enter **Timer** **Setup** menu. After setup, press the **OK** button can add the EPG event to the Timer.

Day EPG:



- 1) Press the **CH+/CH-** button to change channel.
- 2) Press the **VOL+/VOL-** button to change EPG event of the highlighted channel.
- 3) Press the **BLUE** button to display the detail information of the highlighted EPG event.
- 4) Highlight the EPG event which you want, press the **RED** button to enter **Timer Setup** menu. After setup, press the **OK** button can add the EPG event to the Timer.

10.5 Subtitle

You can select the language for the subtitle if the program provides subtitle information.

1. Press the **SUB** button.
2. Select the required subtitle language and press the **OK** button. The subtitle of the selected language will be displayed at the bottom of the screen.

10.6 Teletext

You can view the teletext information of currently watched program.

1. Press the **TXT** button.
2. Press the **CH+/CH-** button to page up or page down.
3. Press the **NUMERIC(0-9)** buttons can go to the designated page directly.
4. Press the color button can back to the previous page.



10.7 Find channel


You can find the channels you want quickly just by pressing the **FIND** button directly.

Or by pressing **Blue button** in **OK List/FAV List**.

10.8 Program Information

You can view the program information by pressing the **INFO** button while watching a program.

1. General Information



 : It is a FTA program.

 : It is a scramble program.

 : The sound of current program is not Dolby.

 : The sound of current program is Dolby.

 : Current program has no EPG information.

 : Current program has EPG information.

 : Current program has no teletext information.

 : Current program has teletext information.

 : Current program is unlocked.



: Current program is locked.




: Current program is not a HD program.



: Current program is a HD program.

2. EPG Information

Press the **INFO** button twice to view detailed EPG information, press the **VOL+ / VOL-** to switch current and next and press the **INFO** button once more to hide the detailed EPG information.



11. Channel List

This chapter will help you manipulate the channel list.

Tip: You can press the **Sat** button to choose different satellite when you are operating on a channel list, press **OK** to confirm, then all the channels of this sat will be display.

11.1 OK List

1) Press the **OK** button to enter the channel list while watching a program.

2) Press the VOL+/VOL- button to switch the channel list type.

(All Channels/ FTA Channels/ Scramble Channels/ HD Channels)


2) Press the **RED** button to sort the channels. Highlight the option you want and press the **OK** button to sort the channel list.

Note: The **Original Channel List** is back to the channel list you sort it last time.

3) Press the **GREEN** button to list the channels by transponder.

4) Press the **YELLOW** button can help you find the channel quick by the first character of name.

5) Press the **BLUE** button to enter the **Quick Find** menu.



11.2 Favorite List

- 1) If you have set several favorite lists, press the **FAV** button can enter the favorite list.
- 2) Press the **VOL+/VOL-** button to change different favorite list and press the **OK** button can select the a program in current favorite list.
- 3) Press the **RED** button to sort the channels of the favorite list.
- 4) Press the **GREEN** button to manipulate the favorite list channels (move, delete, rename, lock/unlock, swap the channels of the favorite list) .
- 5) Press the **YELLOW** button can help you find out channels quick by their first name.
- 6) Press the **BLUE** button can help you quickly find the channel you want.

Note: If you selected a favorite list, press the **CH+/CH-** button can only change the channels in this favorite list and press the **OK** button can only display the channels in this favorite list.

12. USB Control

12.1 Recording and Timeshift

12.1.1 Recording

You can watch another channel from the same TP while recording. And at the same time, you can record two channels in the same TP. You can also do many operations while recording.

1. Start Recording

- 1) You can press the **●** button to start recording while watching program.
- 2) You can switch to another channel and press the **●** button to start the second recording.
- 3) If you have set the timer, and set the **Time Record** on, it will start recording automatically according to the start time of the timer.

2. Stop Recording

- 1) You can press the **■** button to stop recording. If you don't press the **■** button, it will stop recording according to the record duration.
- 2) If you have set the timer, it will stop recording automatically according to the stop time of the timer.
- 3) If the free space on the USB HDD or USB disk is insufficient, recording will stop.

3. Watch the Other Program while Recording

At the same time, you can only watch the program from the same TP.

4. Other Operations while Recording

While the recording channel is current channel, press the **INFO** button can display

the recording time. And press the **INFO** button twice can display the detail information of the recording. Press the ► button will enter the playback mode. Press the ● button can set the record duration. Press the **PAUSE/||** button can pause or play the program. Press the ◀◀/▶▶ button can fast rewind or fast forward in playback mode.

12.1.2 Timeshift

Timeshift allows you to pause a live broadcast and return to it later and continue where you left off.

Press the || button to start timeshift. While it is in timeshift mode, press the ► button can play the program, press the **INFO** button can display the recording information, press the **PAUSE/||** button can pause or play the program, press the ◀◀/▶▶ button can fast rewind or fast forward. Press the ■ button to stop timeshift. If you change to another program or do other operations, timeshift data will be deleted. If automatic timeshift is set, after switching channel, receiver will start timeshift again.

12.2 PVR List


You can enter the PVR list directly and then play the PVR file. In the PVR list you also can delete the PVR files.

1. Press ► button enter the PVR list when watching program.

2. Press the **CH+/CH-** to highlight the PVR file you want to play, press the **OK** button to play in small screen.

3. You can press **BLUE** button to play the PVR file in full screen. And press **Exit** button will return to the PVR List.

4. If you want to delete PVR files, first you must press the **CH+/CH-** to highlight the PVR file you want to delete, and press the **YELLOW** button to delete.



13. Network

By connecting to internet you might have access to selected internet services.

13.1 Connecting to Network

13.1.1 Connecting to the LAN

1. Connect one end of the Ethernet cable to the product and the other end to the LAN router.

2. **Menu->Expansion->IP Setting**

If the Ethernet cable is connected fine, it will display “**Connect**”. In this menu, you can set IP address manually, also you can get IP address automatically.

- **RED**: Get IP address automatically.
- **GREEN**: Test the network if connect correctly.




13.2 Connecting to Wifi (Wireless LAN) - OPTIONAL

Note: this menu is available only after inserting Wifi dongle. After inserting dongle LAN by Ethernet cable will be disabled automatically.

1. Plug in the wireless USB dongle to the USB port.
2. Enter

Menu->EXPANSION->Wireless Setting->Search Access Point.

3. Select the network name of your Wi-Fi access point from the list.
4. Press the **OK** button, then input



the right password.

5. Enter **Menu-> Network->Wireless Setting->IP Situation**.

If the Network is connected, it should get the correct IP address and display the "**Connected**".

13.3 Network Application

13.3.1 Weather Forecast

Here you can input the city name to browse the weather of this city in future days.

- **RED**: Change the city and unit of temperature.
- **GREEN**: Store the current setting.



13.2.2 FTP Download (optional)

You can Download S/W, music, photo and other media files from the FTP.

1. **Menu-> Expansion ->FTP Download**
2. Input the correct information for every option.
3. Highlight on the **Connect Net**, press the **OK** button to enter the FTP.
4. According to the prompted information select the file you want to download and press the OK button to download it to USB device.



14. Additional Information

14.1 Trouble Shooting

Before contacting your local service centre, please read the tips below carefully. If the problem persists after completing the following procedure, please contact your local product distributor or service centre for further instructions.

1. No message displayed on the front display. (The product will not switch on, nothing on display)

- Check the main power cable and make sure it is plugged into a suitable power outlet.
- Check that the mains supply is switched on.
- Connect the power cable to a different power outlet.
- Check that the power switch is on at the rear of the product. (where applicable)

2. No picture

- Make sure that the product is powered on and in operation mode. (Press the STANDBY button, in operating mode Display will show channel number, try to change channels)
- Make sure that the AV/HDMI/YUV cable is firmly connected to the TV. Try to change Video resolution by pressing **Display** button.
- Make sure that the antenna cable is properly connected to the product.
- Be sure to activate channel search.
- Check the brightness level of the TV.
- Check if the channel is currently on air. Contact the broadcaster to ensure that the channel is running.

3. Poor picture/sound quality

- Make sure there is no mobile phone or microwave oven near the product.
- Check that your dish alignment is correct.
- Change the satellite dish for a larger one as this will increase the signal levels received.
- Replace the LNB with a lower noise factor in cases where the noise factor is too high.
- Replace the LNB with a new one in case it is damaged or out of order.
- Check the signal levels and adjust your antenna if the level is too low. The signal level may be affected by weather conditions.

4. No or poor sound

- Check that your AV/HDMI cable is connected correctly.
- Check the volume levels of your TV set and the product.
- Check if the product or TV is on mute.
- Check audio type or soundtrack option. (where applicable)

5. Remote control does not operate.

- To control the product, the top end of the remote control should point directly towards the receiving part of the product.
- Remove and reinsert the batteries in the remote control.
- Replace the batteries in the remote control for a new set.

6. Cannot connect to the network .

- Make sure the network of your family is good.
- Make sure the Ethernet cable is inserted firmly to the LAN router.
- Make sure the Wi-Fi can work on other device (optional)
- Input the Wi-Fi password again. (optional)
- Get auto IP again. Press **green** button to test link.
- Restart the receiver again.

14.2 Declaration of conformity

The manufacturer herewith declares the conformity of that product with the following directives and standards:

Low Voltage Directive 2006/95/EC

EN 60065:2002+A1:2006+A11:2008

EMC Directive 2004/108/EC

EN 55 013:2001+A1:2003+A2:2006

EN 55 020:2007

EN 61 000-3-2:2006+A1:2009+A2:2009

EN 61 000-3-3:2008

Model: Digital Satellite Receiver DVB-S2

14.3 Technical Specification

Tuner & Channel

Frequency Range	950 MHz to 2150 MHz
Signal Level	-25 to -65 dBm
LNB Power	13V/18V/14V/19V OFF, I _{max} = 400mA
LNB Tone Switch	22KHz+/-2KHz, 0.6V _{pp} +/-0.2V
DiSEqC Control	Version DiSEqC 1.0/1.1/1.2/1.3(USALS)Compatible, Tone burst A/B

MPEG

Transport Stream	MPEG-2 ISO/IEC 13818Transport stream specification
Profile Level	MPEG1,MPEG-2 MP@ML,H.264,
Input Rate	80 Mbps for MPEG Transport Stream and 25 Mbps for DV streams
Aspect Ratio	4:3, 16:9
Video Resolution	576i, 576p, 480i, 480p, 720p50, 720p60, 1080i,1080p
Audio Decoding	MPEG-2 layer I and II (Music cam),MPEG4 AAC and MPEG4 AAC-HE (AAC+),Dolby Digital (AC-3) with bit rates up to 640 K bits /s, LPCM up to 48 KHz,
Audio Mode	Single channel/Dual channel/Joint stereo/Stereo
Sampling	32, 44.1 and 48 KHz

Power Supply

Input Voltage	AC 100 ~240V, 50/60Hz
Power Consumption	StandBy mode <1W, Operation mode 15W, Max load 25W
Protection	Separate internal fuse. Input shall have lightning Protection

Physical Specification

Weight (Net)	About 2.5kg
Operating Temp	0℃ to + 40℃
Storage Temp	-40℃ to + 65℃

Weight and dimensions are not absolutely exact values. In order to improve the product, specifications are subject to change (by manufacturer) without notice.